

adaptable DLP trunking 50 x 195 trunking and fittings







Selection chart (p. 706) Wiring capacity chart (p. 726)

Pack	Cat.Nos	Multi-compartment trunkings
8 ⁽¹⁾	2 comp. Cover 85 Cover 40 and 65 B 104 52	Body 50 x 195 mm - Length 2 m Supplied without cover
		Flexible covers Fits onto the whole trunking including in internal or external angles Length 2 m
20 ⁽¹⁾ 20 ⁽¹⁾ 20 ⁽¹⁾	105 20 105 21 105 22	Partial cover, width 40 mm Partial cover, width 65 mm Partial cover, width 85 mm
		Partitions
		Length 2 m
48 ⁽¹⁾	104 72	Division partition,
24 ⁽¹⁾	105 82	for fitting partial covers Separation partition
		Joints
20	106 92	Body joint, attached with adhesive (fit at the end of installation)
20	106 91	Body joint For aligning bases during installation
10	108 00	Cover joints for 40 mm cover
10	108 01	Cover joints for 65 mm cover
10	100 02 1	Cover joints for 85 mm cover

			Angles and end cap
	2 comp. Cover 85	3 comp- Cover 40 and 65	Internal and external angles Include the 2 components for the top and bottom of the trunking on which the flexible cover and 1 and 2 partition joints fit respectively, ensuring continuity of the partitions and holding the covers in place, for 2 and 3 compartment configurations
5	106 06		Changeable internal angle, from 85° to 95° for 50 x 150 and 50 x 195 mm trunkings
5		106 50	Changeable internal angle, from 85° to 95° for 50 x 170 and 50 x 195 mm trunkings
5	106 35		Changeable external angle, from 60° to 120° for 50 x 150 and 50 x 195 mm trunkings
5		106 38	Changeable external angle, from 60 to 120° for 50 x 170 and 50 x 195 mm trunkings

Pack	Cat.Nos	Angles and end cap (continued)	
2	107 92	Flat angle 90° flat angle	
5	107 07	End cap Left or right end cap	
Junctions			
		Flat junctions	
5	107 35	To tap-off to an 80 mm wide trunking	
5	107 37	To tap-off to a 105 mm wide trunking equipped with a 65 mm cover	
5	107 36	To tap-off to a 105 mm wide trunking equipped with an 85 mm cover	
		Angled junction	
5	107 63	To tap-off in an internal angle to 35 x 80, 35 x 105, 50 x 80 or 50 x 105 mm trunking Used with an internal angle Cat.No 106 02, 106 06 or 106 50	
		Accessories	
50	106 82	Clip for 40, 65 and 85 mm covers	
50	106 86	Clip for 180 mm cover	
100	308 81	Base for clamp	

Installation accessories (p. 724)

Dlegrand

adaptable DLP trunking 50 x 195 trunking and fittings





 \odot

Selection chart (p. 706) Wiring capacity chart (p. 726)

Pack	Cat.Nos	Single compartment trunking
8(1)	1 comp. Cover 180 A 104 52	Body 50 x 195 mm Supplied without cover Length 2 m
8 ⁽¹⁾	105 26	Flexible cover Fits onto the whole trunking including in internal or external angles Length 2 m Full cover width 180 mm
24 ⁽¹⁾	105 82	Partition Length 2 m Separation partition
20	106 92	Joints Body joint, attached with adhesive (fit at the end of installation)
20	106 91	Body joint For aligning bases during installation
10	108 06	Cover joint

	Pack	Cat.Nos	Junctions
			Flat junctions
	5	107 35	To tap-off to an 80 mm wide trunking
)	5	107 37	To tap-off to a 105 mm wide trunking equipped with a 65 mm cover
J	5	107 36	To tap-off to a 105 mm wide trunking equipped with an 85 mm cover
			Angled junction
	5	107 63	To tap-off in an internal angle to 35 x 80, 35 x 105, 50 x 80 or 50 x 105 mm trunking Used with an internal angle Cat.No 106 02, 106 06 or 106 50
			Accessories
	50	106 82	Clip for 40, 65 and 85 mm covers
	50	106 86	Clip for 180 mm cover
	100	308 81	Base for clamp

		Angles and end cap
		Internal and external angles Include the 2 components for the top and bottom of the trunking on which the flexible cover is fitted
10	106 02	Changeable internal angle, from 85° to 95° for 50 x 80/50 x 105/50 x 150 and 50 x 195 mm trunkings
10	106 22	Changeable external angle, from 60° to 120° for 50 x 80/50 x 105/50 x 150 and 50 x 195 mm trunkings
2	107 92	Flat angle 90° flat angle
5	107 07	End cap Left or right end cap

Installation accessories (p. 724)